

Cetol® UV Interior APPLICATION

Cetol® UV Interior

■ Preparation Procedures

New, Unfinished Wood

Cleaning Recommendation

1. Clean the surface with a solution of 4 ounces of 100% powdered Tri-Sodium Phosphate (TSP) or phosphate-free substitute in 1 gallon of warm water. Do not allow cleaning solution to dry on surface. Use a damp cloth or sponge to remove residue from the surface and allow to thoroughly dry.
2. Fill all holes and cracks with a good quality tinted or stained acrylic wood filler to match the color of the project. Let dry fully before sanding. Do not use oil based fillers, putties, or wax sticks.
3. Sand the surface 150-180 grit sandpaper. Always sand wood with the grain to achieve a smoother surface without sanding marks. Remove sanding dust by vacuuming then wipe surface with a damp cloth to remove final dust particles.

Cetol® UV Interior APPLICATION

■ Application Procedures

New/Bare Wood Applications

1. Follow the preparation procedures.
2. Apply 1st coat of Cetol UV Interior.
3. Let surface dry for minimum of 2 hours.
4. Lightly sand with 220 grit sandpaper, or a fine scuffing pad, and remove the dust.
5. Apply 2nd coat of Cetol UV Interior.
6. Clean tools with soap and water.

Tips

- *Smooth wood coverage: 450-550 sq. ft./US gallon (11-13.5 sq. m./liter)*
- *Avoid direct sunlight that may cause uneven absorption because of open time and poor penetration of the product.*

Application Do's...

- *Intermix different batches together to ensure color consistency.*
- *Apply when the surface and air temp is 50°F/10°C to 95°F/35°C.*
- *Gently stir the product before application; shaking can cause bubbles in the finish.*
- *Apply two coats using synthetic nylon-polyester brush or pad.*
- *Apply in a well ventilated area.*
- *Apply in the direction of the wood grain.*

Application Don'ts...

- *Do not apply if humidity is over 80%.*
- *Do not apply in high wear areas such as kitchen cabinets, doors, furniture or floors.*
- *Do not apply in areas of high humidity such as bathrooms and poolrooms.*
- *Do not apply over previous coatings. Use on bare wood only.*
- *Do not apply on dark woods.*

Cetol® UV Interior APPLICATION

■ Maintenance Procedures

The longevity of the coating system depends on many factors such as daily wear-and-tear and exposure to UV light. Simply apply a refresher coat of Cetol UV Interior when required by following the procedure below:

1. Follow the preparation procedures using the above cleaning solution reducing it to 2 ounces of 100% powdered Tri-Sodium Phosphate or phosphate-free substitute.
2. Sand the project with 220 grit sandpaper. Before coating, vacuum all remaining dust and use a damp cloth to wipe the surface.
3. Apply one coat of Cetol UV Interior.
4. Clean tools with soap and water.